

## Update Firmware and Fonts

### FGL40, FGL21 and FGL41 printers


This ZIP file contains the latest available firmware and resident fonts for the Boca FGL40/21/41 printers:

- FONTA00.FNT**     Resident Font file for all FGL40, FGL21 and FGL41 printers.  
There is no need to update the fonts in a good working printer.
- F40AE0.FNT**     Resident Font file for all FGL40, FGL21 and FGL41 printers. (with EURO sign in Font8 & Font13)  
There is no need to update the fonts in a good working printer.
- FGLB9.BIN**        Firmware file for FGL40, FGL21 and FGL41 printers.


The firmware version can be found on the self-test ticket (or display) of the printer. Please make a note of the original firmware and fonts version before updating the printer.

You can use the Boca Customer program to update your printer, this program can be downloaded from our website at "Test Program & Firmware". <http://www.tls-bocasystems.com/en/53/test-program-firmware>

Make sure you always update your customer program to the latest version by pressing the "Check For Update" button as shown on the right.



Connect with your printer. At Printer Configuration select either Update Firmware (or Update Font) to upload the file into the printer.



After updating, the printer will re-initialize. The new firmware and resident font version should be visible on the display (or at the self-test ticket).

If you have any questions, feel free to contact us.

Kind Regards,

TLS - Boca Systems  
[support@tls-bocasystems.com](mailto:support@tls-bocasystems.com)